

# Production Run Sampling – Transdermal Patches

Calculate 1% of the production run, round up to the nearest unit. Choose the lesser value of 1% or 25 units. This is your production run sample amount. The minimum is 3 units regardless of the production run size

